



**TREMOLO NOTES**

- NOTE 1: Change to 0.022uF for slower speed.
- NOTE 2: Cap not shown on original Hoffman layout.
- NOTE 3: Change to 100K-220K for stronger tremolo.
- NOTE 4: Change to 0.047uF for stronger tremolo.

Connect filament CT to chassis or use artificial CT IAW Hoffman layout









